

Daily Checks & Maintenance Nordberg C-Jaw Crushers

Before starting ...

1. Check the tension of the V-belts.
2. Check the tightness of the jaw bolt nuts. The washer must be in the level with the disc spring housing (0-0.5mm or 0-0.02”).
3. Check the tightness of the cheek plate bolts and tighten to the proper torque per factory settings.
4. Check that the protection rubber of the toggle plate is in good condition and in place.
5. Check the tightness of the tightening rod nuts. The washers must be in the level with the disc spring housing (0-0.5mm or 0-0.02”).
6. Clean all safety signs and ensure that they are legible.
7. Active setting control: Drive the setting to the minimum and to the maximum to ensure the functioning of the lubrication.
8. Active setting control: Check for possible oil leaks.

For additional information or if you would like help setting up a daily maintenance checklist, please contact Midsouth Machine & Service at (865) 970-7900.

DANGER

*Lockout power source during
installation, cleaning or servicing
equipment or when making repairs.
Failure to do so could result in severe
bodily injury or death.*